


EB-710Ui EB-700U

Installation Guide





Safety Instructions

For your safety, read all the instructions in this guide before using this product. Incorrect handling that ignores instructions in this guide could damage this product or could result in personal injury or property damage. Keep this installation guide at hand for future reference.

Read the User's Guide and Safety Instructions for your projector and follow the instructions in these documents.

Safety indications

The documentation and this product use graphical symbols to show how to use this product safely.

The indications and their meaning are as follows. Make sure you understand them properly before reading the guide.

Symbol	Explanation	
Warning This symbol indicates information that, if ignored, could possibly result in personal injueven death due to incorrect handling.		
Caution This symbol indicates information that, if ignored, could possibly result in personal inju- physical damage due to incorrect handling.		

Explanation of Symbols

Symbols	Explanation	
\bigcirc	Symbol indicating an action that must not be done	
0	Symbol indicating an action that should be done	
	Symbol indicating related or useful information	

Safety Precautions for Installation

🕂 Warning	
The setting plate is exclusively for mounting the projector on a wall. If anything other than a projector is mounted, the weight may result in damage.	0
If this product falls, it could cause death or personal injury.	
The installation work (wall mounting) should be performed by specialists who have tech- nical knowledge and ability. Incomplete or incorrect installation could cause the product to fall and cause personal injury or property damage.	0
Follow the instructions in this guide when installing this product.	0
If the instructions are not followed, this product may fall, resulting in personal injury or an accident.	

Warning	
Handle the power cord carefully.	
Incorrect handling may cause fire or electric shock. Observe the following precautions when han- dling:	
 Do not handle the power plug with wet hands. Do not use a power cord that is damaged or modified. Do not pull the power cord with too much force when routing the cable through the setting plate. 	
Do not install the setting plate in a place where it might be subjected to vibration or shock.	\bigcirc
This could cause damage to the projector or mounting surface. If this product falls, it could cause death or personal injury.	
Install the setting plate so that it can sufficiently support the mass of the projector and setting plate, and resist any horizontal vibration. Use M10 nuts and bolts.	0
Nuts and bolts smaller than M10 could cause the setting plate to fall. Epson accepts no responsibility for any damage or injury caused by lack of wall strength or inadequate installation.	
The installation work should be performed by at least two qualified service personnel. If you need to loosen any screws during installation, be careful not to drop this product.	0
If this product falls, it could cause death or personal injury.	
When mounting this product on a wall, the wall requires enough strength to hold the projector and the setting plate.	0
This product should be installed on a concrete wall. The maximum combined weight of the pro- jector and the setting plate is approximately 20 kg (not including cables). Ensure the strength of the wall before mounting this product on the wall. If the wall is not strong enough, reinforce the wall before installation.	
Inspect the setting plate on a regular basis to ensure there are no broken parts or loose screws.	\bigcirc
If any parts are damaged, stop using the setting plate immediately. If this product falls, it could cause death or personal injury.	
Do not disassemble or remodel this product.	\bigcirc
There are numerous high-voltage sections inside the product that could cause a fire, electric shock, or an accident.	
Do not hang on this product or hang a heavy object on this product.	\bigcirc
If this product falls, it could cause death or personal injury.	
Do not use adhesives, lubricants, or oils to install or adjust the setting plate.	\bigcirc
If you use adhesives to prevent the screws from loosening or things such as lubricants or oils on the slide plate fixing part of the projector, the case may crack and cause the projector to fall, resulting in personal injury or property damage.	U
Tighten all screws firmly after adjustment.	
Otherwise, the product may fall and cause personal injury or property damage.	
Never loosen the bolts and nuts after installation.	\bigcirc
Confirm that the screws have not become loose on a regular basis. If you find any loose screws, tighten them firmly. Otherwise, the product may fall and cause personal injury or property damage.	
Route the cables so that they are not interfered with the nuts and bolts.	
Incorrect handling of the cables may cause fire or electric shock.	

Warning	
When turning on the projector, do not look into the projection window.	\bigcirc
This could cause damage to eyesight due to the powerful light emitted. Take particular care when there are children present. When turning on the projector at a distance using the remote control, make sure there is no one looking into the projection window.	G
When using the projector, do not place any objects or put your hand near the projection window.	\bigcirc
This area is dangerous as it reaches a high temperature due to the concentrated projection light.	
Do not cover the projector's air intake vent or air exhaust vent. If either of the vents are covered, the internal temperature could rise and cause a fire.	\bigcirc
Avoid locations subject to high temperatures, such as close to heaters, and leave a gap of at least 50 cm between the wall and the air exhaust vent.	
Do not use the projector in a location subject to combustible or explosive gas.	\bigcirc
The projector may catch fire because of the high temperature inside the projector.	<u> </u>
If any abnormalities occur with this product, immediately disconnect the cables from the product, and then contact your local dealer or the nearest Epson service call center.	0
Continuing to use the product in an abnormal condition could cause a fire, electric shock, or visual impairment.	
Laser warning labels are attached to the inside and the outside of the projector.	\bigcirc
Inside	$\mathbf{\circ}$
<u>Autoron / DANGER</u> CANTON / DANGER: EN CASS & LASER RADDITION WHEN OPEN AND SEVERATION OF EXAMINES AND THE RADDITION WHEN OPEN AND SEVERATION OF EXAMINES AND THE AND AND AND SEVERATION OF EXAMINES AND	
As with any bright source, do not stare into the beam, RG2 IEC/EN 62471-5:2015.	
Line Line <thline< th=""> Line <thline< th=""> <thline< th=""> Line</thline<></thline<></thline<>	
Never open any cases on the projector.	\bigcirc
Electrical voltages inside the projector can cause severe injury.	_

🕂 Warning		
Do not look at operating light source.	\bigcirc	
Possibly hazardous optical radiation emitted from this product. Eye injury may result.	0	
Caution		
Do not install this product in a location where the operating temperature for your projector model may be exceeded.	\bigcirc	
Such an environment may damage the projector.		
Install this product in a place free from excessive dust and humidity to prevent the lens or optical components from becoming dirty.		
Do not use excessive force when adjusting this product.	\bigcirc	
This product may break, resulting in personal injury.		
This projector is a Class 1 laser product that complies with the IEC/EN60825-1: 2014 international standard for lasers.	0	
Do not disassemble the projector when disposing of it.	\bigcirc	
Dispose according to your local or national laws and regulations.		

Notes on handling the Touch Unit (EB-710Ui only)

Warning	
Do not disassemble or remodel the Touch Unit.	\bigcirc
The Touch Unit contains a high power laser product that could cause a fire, electric shock, or an accident.	
Only connect the Touch Unit to the EB-710Ui. Do not connect it to any other projectors or devices.	\bigcirc
The device could malfunction, or laser light that is higher than normal intensity could be emitted.	
Do not go near the Touch Unit if you are using medical equipment such as a pace maker. Furthermore, when using the Touch Unit, make sure there is no one using medical equip- ment such as a pace maker, in the surrounding area.	•
A powerful magnet within the unit generates electromagnetic interference which may cause med- ical equipment to malfunction.	
Caution	
Do not go near the Touch Unit with magnetic storage media such as magnetic cards, or precision electronic devices such as computers, digital watches, or mobile phones.	\bigcirc
A powerful magnet within the unit could corrupt data or cause a malfunction.	
Do not disassemble the touch unit when disposing of it.	
Dispose according to your local or national laws and regulations.	

About This Installation Guide


This guide describes how to mount the ultra short-throw projector EB-710Ui/EB-700U on a wall.

It also explains how to install the Touch Unit after mounting the projector on a wall (EB-710Ui only).

Choosing an Installation Location


Projector installation location

- Carry out power supply wiring work for the installation location of the setting plate in advance.
- Install the projector away from other electric devices such as fluorescent lights or air conditioners. Some kinds of fluorescent lights could interfere with the remote control of the projector.
- When installing the projector, make sure there is a gap of at least 50 cm from the wall to the projector's air exhaust and intake vents on the left and right.



• When installing two or more projectors in parallel, make sure the temperature of the surrounding environment is less than 35°C.


If the environment is too hot, the projector may overheat and the power may turn off without warning. When using the projector in an environment of 35°C or more, install a partition to block the heat vented from the projector's air exhaust vent. Make sure the partition is slightly larger than the exhaust vent (approx. 2 cm wider and taller), and then install the partition 30 cm from the exhaust vent.




- It is recommended to keep connection cable length less than 20 meters to reduce external noise.
- We recommend using stick-on screens or board screens.
- Install the projector so that it is tilted at an angle of no more than $\pm 3^{\circ}$ vertically and horizontally in relation to the screen.
- When using the interactive function (Easy Interactive Function), install so that the projected image is within reach.
- Do not install the projector or the screen in a location subject to direct sunlight. If the projector or the screen are subject to direct sunlight, the interactive function may not operate correctly.

Touch Unit Installation Location (EB-710Ui only)


- When using the Touch Unit, install the projector using one of the following methods. The Touch Unit cannot be used if another installation method is used.
 - Mount the projector on a wall or suspend it from a ceiling and project images from in front of the screen.
 - Install vertically on a table and project from the front of the desk. (When installing vertically on a table, you need the optional Interactive Table Mount (ELPMB29).)
- Before installing the Touch Unit, make sure that the installation surface is not warped or distorted, and that any unevenness on the screen surface is less than 5 mm.




• When installing the Touch Unit on a whiteboard, secure the Touch Unit with magnets or screws.



• When installing the Touch Unit outside the whiteboard, you need the supplied Touch Unit Bracket.



- If the distance from the wall to the surface of the screen (f) is more than 50 mm, you cannot install the Touch Unit outside the whiteboard.
- If there is a frame around the screen, make sure that the thickness of the top of the frame (e) is less than 3 mm. If the thickness of the top of the screen exceeds 3 mm, the Touch Unit will not operate correctly.



-

Using the Product Safely

Safety Instructions 1
Safety indications 1
Explanation of Symbols
Safety Precautions for Installation
Notes on handling the Touch Unit (EB-710Ui only)
About This Installation Guide
Choosing an Installation Location 6
Projector installation location
Touch Unit Installation Location (EB-710Ui only)

Installation Guide

Installation Work Flow 11
Installing one projector
When two or more projectors are installed in parallel
Package Contents 13
Setting plate
Touch Unit (EB-710Ui only)
Touch Unit Bracket 14
Specifications 15
Setting plate 15
Wall plate cover
Wall plate
Vertical slide adjustment range
Horizontal slide adjustment range 17
Forward/backward slide adjustment range
Position for installing accessories
Touch Unit (EB-710Ui only)
Touch Unit (external dimensions/weight)
Touch Unit Bracket (external dimensions/ adjustment range/weight)
Attached labels
Laser diffusion port
Projection Distance Table 22
Figures of Installation Dimensions

When installing the Touch Unit (EB-710Ui only)	22
When Projected Image is Smaller than 85 Inches	25
	26
16:10 projected image	27
16:9 projected image (EB-700U only)	28
4:3 projected image (EB-700U only)	29
When Projected Image is 85 inches or more \ldots .	30
16:10 projected image	31
16:9 projected image (EB-700U only)	33
4:3 projected image (EB-700U only)	35
Installing the Setting Plate	37
Connecting Devices	37
Necessary cables	37
Installation Procedure	39
Assemble the parts	39
Install the wall plate on the wall $\ldots \ldots \ldots$	41
Determine the projection distance, and then pass the cables through the setting plate	43
Attaching the setting plate to the wall plate	
· · · · · · · · · · · · · · · · · · ·	45
Securing the projector to the setting plate	47
Adjusting the Position of the Projector	
Sticking the infrared deflectors (EB-710Ui only)	55
Arc Correction	
Calibrating the Pen (EB-710Ui only)	
Attaching the Covers	
Installing the Touch Unit (EB-710Ui	
only)	65
When installing the Touch Unit outside the whiteboard (using the Touch Unit Bracket)	65
Installation Procedure	65
Angle Adjustment	71
Touch Calibration	86
When installing the Touch Unit on the whiteboard (without using the Touch Unit Bracket)	89
Installation Procedure	89
Angle Adjustment	93

-

Appendix

Installing Multiple Projectors in
Parallel (Multi-Projection)
Multi-Projection settings
Setting the Projector ID
Adjusting the Image in Multi-Projection 100
When two projectors are installed in parallel and you are using the interactive function (EB-710Ui only)
Setting the projectors in sync 101
Setting Multi-Projection Interactive 103
Batch Setup Function 110
Setup Using a USB flash drive
Saving settings to the USB flash drive \ldots . 111
Copying saved settings to other projectors
Setup by Connecting the Computer and
Projector with a USB Cable 114
Saving settings to a computer
Copying saved settings to other projectors
When Setup Fails 116
Attaching a Security Cable
General Notice 118

Installation Work Flow

Installing one projector

Follow the procedures below to mount the projector on a wall.




- 2 Adjusting the Position of the Projector (p.49)

When installing the Touch Unit, finish installing the projector first, and then follow the procedures below. (EB-710Ui only)


The procedure differs depending on where the Touch Unit is to be installed.

When installing the Touch Unit outside the whiteboard (using the Touch Unit Bracket)



- 1 Installing the Touch Unit (p.65)
- **3** Performing Touch Calibration (**• p.86**)


When installing the Touch Unit on the whiteboard (without using the Touch Unit Bracket)



- 1 Installing the Touch Unit (
 p.89)
- **3** Performing Touch Calibration (
 p.86)


When two or more projectors are installed in parallel

When using the multi-projection function (when multiple projectors are installed in parallel to project one, large screen), follow the steps below.



- Adjusting the Image in Multi-Projection (p.100)

When two projectors are installed in parallel and you want to use the interactive function, make the following settings (EB-710Ui only). Make the settings for each projector in turn.








Setting plate

The following supplied items are necessary to mount the projector on a wall. Confirm that you have all items before beginning. Depending on the area in which you purchased the product, the Setting Plate is not supplied. In this situation, purchase the optional Setting Plate ELPMB53.



End cap

Masking sticker

Hexagon wrench (for M4)


Open-ended spanner 13 mm (for M8 and M6), 6 mm (for hexagonal axis)

Shape	Name	Quan- tity	Application
8	M4 x 12 mm hexagon socket head cap bolt	5	For wall plate assembly
	with washer/spring washer	4	For 3-axis adjustment unit/arm installation
		4	For slide plate/projector installation
O _O	M6 x 20 mm hexagon shoulder head bolt with washer/spring washer	1	For setting plate/wall plate installation
	M6 x 20 mm cross recessed head shoulder screws with plastic washers	3	

- Use the bolts or screws supplied with this product to install it as directed in this guide. Do not substitute these bolts with any other types.
- You need to use commercially available M10 x 60 mm anchors (at least 4) and one M10 screw to attach the wall plate to the wall.
- Gather the tools and parts you need before you begin installation.

Touch Unit (EB-710Ui only)


The following supplied products are necessary when attaching the Touch Unit. Confirm that you have all items before beginning. When installing the Touch Unit outside the whiteboard, use the supplied Touch Unit Bracket.



Tape for securing the markers (approx. 6 cm) x12

When installing the Touch Unit on a non-magnetic whiteboard, prepare three commercially available M4 screws.

Touch Unit Bracket



For the installation plate, you also need three commercially available 4 mm diameter wood screws, or three M4 anchor bolts.

Specifications


Setting plate

ltem	Specification	Remark	Reference Page
Setting plate weight	Approx. 7.9 kg	Setting plate, 3-axis adjustment unit, slide plate, wall plate, wall plate covers/end caps	
Maximum load capacity	13.0 kg		
Forward/backward slide ad- justment range	0 to 320 mm	Adjustment for 3-axis adjustment unit in- stallation position: 87 mm	See the fig- ure below
Vertical slide adjustment range	±38 mm		See the fig- ure below
Horizontal roll adjustment range	±3°	Fine adjustments possible with adjust- ment dial	☞ p.49
Horizontal rotation adjustment range	±8°	Fine adjustments possible with adjust- ment dial	☞ p.49
Vertical tilt adjustment range	±3°	Fine adjustments possible with adjust- ment dial	☞ p.49
Horizontal slide adjustment range	±45 mm		See the fig- ure below

Wall plate cover

The following dimensions apply when attaching the wall plate cover.

[Unit: mm]




When installing the wall plate cover, you need a space of approximately 263 mm from the center of the wall plate to the left side, and approximately 253 mm to the right side.

Wall plate

The following figure shows two frames connected to one plate (separate when shipped).

[Unit: mm]


[Unit: mm]




* The offset value for the position of the center of the projected image and the center of the wall plate is 27 mm.

Cable routing holes

When routing cables to connect to the projector through a wall, use positions (\boxed{A}) and (\boxed{B}) in the following figure as the cable routing holes.




Vertical slide adjustment range



Horizontal slide adjustment range

[Unit: mm]




Forward/backward slide adjustment range

Arm slide adjustment range

Adjustment range for 3-axis adjustment unit installation position


[Unit: mm]

[Unit: mm]




Position for installing accessories

These screw holes allow you to secure peripheral devices and accessories such as external tuners. Use commercially available M4 screws.



Touch Unit (EB-710Ui only)

Touch Unit (external dimensions/weight)




The Touch Unit weighs approximately 450 g.

Touch Unit Bracket (external dimensions/adjustment range/weight)

Тор


[Unit: mm]

[Unit: mm]




Front

[Unit: mm]




Installation plate (front)

[Unit: mm]



When the Touch Unit is installed (side)


[Unit: mm]



Touch Unit Bracket weights approximately 750 g.

Attached labels

The Touch Unit is a Class 1 laser product that conforms to the IEC/EN60825-1:2014 standard. There are warning labels affixed to the Touch Unit to indicate that it is a Class 1 laser product.




The labels contain the following information.

- Class 1 laser product
- Warning: Do not open the case. The device contains a high power laser product.
- Warning:

- Caution: If this section is opened, class 3B invisible laser radiation will be emitted.
- Avoid exposure to the radiation beams.

Laser diffusion port

The laser beam is diffused from the laser diffusion ports at the back of the Touch Unit.



- Light source output power: Maximum 285 mW x 2
- Wavelength: 932 960 nm


Projection Distance Table

Figures of Installation Dimensions


To find the appropriate projection distance, see the following figures when installing. The values are only rough estimates.

The recommended range for the projection distance (a) is 62 to 432 mm.

The offset value for the position of the center of the projected image and the center of the wall plate is 27 mm. [Unit: mm]




Aspect ratio for standard projected image



When installing the Touch Unit (EB-710Ui only)

By using the supplied Touch Unit Bracket, you can install the Touch Unit outside the whiteboard.

When installing the Touch Unit outside the whiteboard, measure the length from the surface where the Touch Unit is installed to the whiteboard surface ((f) in the following figure).




- When (f) is 20 to 50 mm, you can install the Touch Unit outside the whiteboard using the bracket.
- When (f) is less than 20 mm or more than 50 mm install the Touch Unit on the whiteboard.
- When the thickness of the top of the frame (e) is 3 mm or more, install the Touch Unit on the whiteboard.

🚹 Caution

Install the bottom edge of the Touch Unit so that it is 25 to 100 mm from the top edge of the projected image.

If there are obstacles between the projected image and the Touch Unit such as cables, whiteboard trays, or holders, the Touch Unit will not operate correctly.

L.



When the Touch Unit is installed outside the whiteboard (using the Touch Unit Bracket)

[Unit: mm]


If there are any obstacles such as a frame or tray at the bottom of the screen, touch operations will not operate correctly. Stick the supplied infrared deflectors along the locations of the obstacles (
 p.55). Make sure there is a space of approximately 20 mm between the place where the infrared deflector is stuck and the bottom of the projected image.

L.


When installing the Touch Unit on the whiteboard (without using the Touch Unit Bracket)

You need to leave at least 120 mm distance between the top edge of the projected image and the top edge of the actual screen.

[Unit: mm]




- If there are any obstacles such as a frame or tray at the bottom of the screen, touch operations will not operate correctly. Stick the supplied infrared deflectors over the locations of the obstacles (
 p.55). Make sure there is a space of at least 20 mm between the place where the infrared deflector is stuck and the bottom of the projected image.
 - If there are obstacles in the shaded areas in the following figure, such as cables, whiteboard trays, holders, or a thick frame, touch operations will not operate correctly.



When Projected Image is Smaller than 85 Inches


Mount the 3-axis adjustment unit at the position marked with a \bigcirc stamp (\boxed{A}).

The projection distance table provides the figures when mounting the 3-axis adjustment unit at the position marked with a \bigcirc stamp (\boxed{A}).



The distance from the top of the projected image to the bottom wall plate installation screw hole (c) is the number given when the vertical slide is set to the standard position (B).

Match the notch on the setting plate to the position of the stamp on the wall plate.



16:10 projected image

[Unit: cm]

	S	а	b	с	d	h
Proje	ected image size	Projection Dis- tance Minimum (Wide) to Maxi- mum (Tele)	Numbers on the arm slide scale	Distance to the bottom wall plate in- stallation screw hole	Distance from the top of the projected im- age to the wall plate tempora- ry securing screw hole	Height of pro- jected image
70"	150.8x94.2	5.6 to 20.9	16.5 to 31.8	23.7	42.9	94.3
71"	152.9x95.6	6.2 to 21.8	17.1 to 32.7	24.0	43.2	95.6
72"	155.1x96.9	6.8 to 22.6	17.7 to 33.5	24.3	43.5	96.9
73"	157.2x98.3	7.4 to 23.5	18.3 to 34.4	24.6	43.8	98.2
74"	159.4x99.6	8.1 to 24.3	19.0 to 35.2	24.8	44.0	99.7
75"	161.5x101.0	8.7 to 25.2	19.6 to 36.1	25.1	44.3	101.0
76"	163.7x102.3	9.3 to 26.0	20.2 to 36.9	25.4	44.6	102.3
77"	165.9x103.7	10.0 to 26.9	20.9 to 37.8	25.7	44.9	103.6
78"	168.0x105.0	10.6 to 27.7	21.5 to 38.6	26.0	45.2	105.0
79"	170.2x106.3	11.2 to 28.6	22.1 to 39.5	26.2	45.4	106.4
80"	172.3x107.7	11.8 to 29.4	22.7 to 40.3	26.5	45.7	107.7
81"	174.5x109.0	12.5 to 30.3	23.4 to 41.2	26.8	46.0	109.0
82"	176.6x110.4	13.1 to 31.1	24.0 to 42.0	27.1	46.3	110.4
83"	178.8x111.7	13.7 to 32.0	24.6 to 42.9	27.4	46.6	111.7
84"	180.9x113.1	14.3 to 32.8	25.2 to 43.7	27.6	46.8	113.1

Images smaller than 70 inches are not projected correctly.

-WWW • The values are only rough estimates. The value may differ depending on the location where you place the projector.

16:9 projected image (EB-700U only)

[Unit: cm]

	S	а	b	с	d	h
Proje	ected image size	Projection Dis- tance Minimum (Wide) to Maxi- mum (Tele)	Numbers on the arm slide scale	Distance to the bottom wall plate in- stallation screw hole	Distance from the top of the projected im- age to the wall plate tempora- ry securing screw hole	Height of pro- jected image
70"	155.0x87.2	6.8 to 22.6	17.7 to 33.5	29.1	48.3	87.2
71"	157.2x88.4	7.4 to 23.5	18.3 to 34.4	29.5	48.7	88.4
72"	159.4x89.7	8.1 to 24.3	19.0 to 35.2	29.8	49.0	89.7
73"	161.6x90.9	8.7 to 25.2	19.6 to 36.1	30.2	49.4	90.9
74"	163.8x92.1	9.4 to 26.1	20.3 to 37.0	30.5	49.7	92.2
75"	166.0x93.4	10.0 to 26.9	20.9 to 37.8	30.9	50.1	93.4
76"	168.2x94.6	10.6 to 27.8	21.5 to 38.7	31.3	50.5	94.6
77"	170.5x95.9	11.3 to 28.7	22.2 to 39.6	31.6	50.8	95.9
78"	172.7x97.1	11.9 to 29.6	22.8 to 40.5	32.0	51.2	97.1
79"	174.9x98.4	12.6 to 30.4	23.5 to 41.3	32.3	51.5	98.4
80"	177.1x99.6	13.2 to 31.3	24.1 to 42.2	32.7	51.9	99.6
81"	179.3x100.9	13.9 to 32.2	24.8 to 43.1	33.0	52.2	100.9
82"	181.5x102.1	14.5 to 33.0	25.4 to 43.9	33.4	52.6	102.1
83"	183.7x103.4	15.2 to 33.9	26.1 to 44.8	33.8	53.0	103.3
84"	186.0x104.6	15.8 to 34.8	26.7 to 45.7	34.1	53.3	104.6

Images smaller than 70 inches are not projected correctly.

Linne, I

• The values are only rough estimates. The value may differ depending on the location where you place the projector.

4:3 projected image (EB-700U only)

[Unit: cm]

						-
	S	а	b	с	d	h
Proje	ected image size	Projection Dis- tance Minimum (Wide) to Maxi- mum (Tele)	Numbers on the arm slide scale	Distance to the bottom wall plate in- stallation screw hole	Distance from the top of the projected im- age to the wall plate tempora- ry securing screw hole	Height of pro- jected image
70"	142.2x106.7	11.4 to 28.8	22.3 to 39.7	26.3	45.5	106.7
71"	144.3x108.2	12.1 to 29.7	23.0 to 40.6	26.6	45.8	108.2
72"	146.3x109.7	12.8 to 30.7	23.7 to 41.6	27.0	46.2	109.7
73"	148.3x111.3	13.5 to 31.7	24.4 to 42.6	27.3	46.5	111.2
74"	150.4x112.8	14.2 to 32.6	25.1 to 43.5	27.6	46.8	112.8
75"	152.4x114.3	14.9 to 33.6	25.8 to 44.5	27.9	47.1	114.3
76"	154.4x115.8	15.6 to 34.5	26.5 to 45.4	28.2	47.4	115.8
77"	156.5x117.3	16.3 to 35.5	27.2 to 46.4	28.5	47.7	117.4
78"	158.5x118.9	17.0 to 36.5	27.9 to 47.4	28.9	48.1	118.8
79"	160.5x120.4	17.8 to 37.4	28.7 to 48.3	29.2	48.4	120.4
80"	162.6x121.9	18.5 to 38.0	29.4 to 48.9	29.5	48.7	121.9
81"	164.6x123.4	19.2 to 38.0	30.1 to 48.9	29.8	49.0	123.5
82"	166.6x125.0	19.9 to 38.0	30.8 to 48.9	30.1	49.3	125.0
83"	168.7x126.5	20.6 to 38.0	31.5 to 48.9	30.4	49.6	126.5
84"	170.7x128.0	21.3 to 38.0	32.2 to 48.9	30.8	50.0	128.0

Images smaller than 70 inches are not projected correctly.


Linne, I

• The values are only rough estimates. The value may differ depending on the location where you place the projector.

When Projected Image is 85 inches or more


Mount the 3-axis adjustment unit at the position marked with a $\bigcirc\bigcirc$ stamp (A).

The projection distance table provides the figures when mounting the 3-axis adjustment unit at the position marked with a \bigcirc stamp (\boxed{A}).



The distance from the top of the projected image to the bottom wall plate installation screw hole (c) is the number given when the vertical slide is set to the standard position (B).

Match the notch on the setting plate to the position of the stamp on the wall plate.



16:10 projected image

[Unit: cm]

	S	а	b	с	d	h
Proje	cted image size	Projection Distance Minimum (Wide) to Maximum (Tele)	Numbers on the arm slide scale	Distance to the bottom wall plate installa- tion screw hole	Distance from the top of the projected im- age to the wall plate tempora- ry securing screw hole	Height of pro- jected image
85"	183.1x114.4	15.0 to 33.7	17.2 to 35.9	27.9	47.1	114.5
86"	185.2x115.8	15.6 to 34.5	17.8 to 36.7	28.2	47.4	115.8
87"	187.4x117.1	16.2 to 35.3	18.4 to 37.5	28.5	47.7	117.1
88"	189.5x118.5	16.9 to 36.2	19.1 to 38.4	28.8	48.0	118.4
89"	191.7x119.8	17.5 to 37.0	19.7 to 39.2	29.1	48.3	119.8
90"	193.9x121.2	18.1 to 37.9	20.3 to 40.1	29.3	48.5	121.2
91"	196.0x122.5	18.7 to 38.7	20.9 to 40.9	29.6	48.8	122.5
92"	198.2x123.9	19.4 to 39.6	21.6 to 41.8	29.9	49.1	123.8
93"	200.3x125.2	20.0 to 40.4	22.2 to 42.6	30.2	49.4	125.2
94"	202.5x126.5	20.6 to 41.3	22.8 to 43.5	30.5	49.7	126.5
95"	204.6x127.9	21.3 to 42.1	23.5 to 44.3	30.7	49.9	127.9
96"	206.8x129.2	21.9 to 43.0	24.1 to 45.2	31.0	50.2	129.2
97"	208.9x130.6	22.5 to 43.2	24.7 to 45.4	31.3	50.5	130.6
98"	211.1x131.9	23.1 to 43.2	25.3 to 45.4	31.6	50.8	131.9
99"	213.2x133.3	23.8 to 43.2	26.0 to 45.4	31.9	51.1	133.2
100"	215.4x134.6	24.4 to 43.2	26.6 to 45.4	32.1	51.3	134.7
101"*	217.5x136.0	25.0 to 43.2	27.2 to 45.4	32.4	51.6	136.0
102"*	219.7x137.3	25.6 to 43.2	27.8 to 45.4	32.7	51.9	137.3
103"*	221.9x138.7	26.3 to 43.2	28.5 to 45.4	33.0	52.2	138.6
104"*	224.0x140.0	26.9 to 43.2	29.1 to 45.4	33.3	52.5	140.0
105"*	226.2x141.4	27.5 to 43.2	29.7 to 45.4	33.5	52.7	141.4
106"*	228.3x142.7	28.2 to 43.2	30.4 to 45.4	33.8	53.0	142.7
107"*	230.5x144.0	28.8 to 43.2	31.0 to 45.4	34.1	53.3	144.0
108"*	232.6x145.4	29.4 to 43.2	31.6 to 45.4	34.4	53.6	145.4
109"*	234.8x146.7	30.0 to 43.2	32.2 to 45.4	34.7	53.9	146.7
110"*	236.9x148.1	30.7 to 43.2	32.9 to 45.4	34.9	54.1	148.1
111"*	239.1x149.4	31.3 to 43.2	33.5 to 45.4	35.2	54.4	149.4
112"*	241.2x150.8	31.9 to 43.2	34.1 to 45.4	35.5	54.7	150.8
113"*	243.4x152.1	32.6 to 43.2	34.8 to 45.4	35.8	55.0	152.1
114"*	245.5x153.5	33.2 to 43.2	35.4 to 45.4	36.1	55.3	153.4
115"*	247.7x154.8	33.8 to 43.2	36.0 to 45.4	36.3	55.5	154.9

Line in the second seco

	S	а	b	с	d	h
Proje	ected image size	Projection Distance Minimum (Wide) to Maximum (Tele)	Numbers on the arm slide scale	Distance to the bottom wall plate installa- tion screw hole	Distance from the top of the projected im- age to the wall plate tempora- ry securing screw hole	Height of pro- jected image
116"*	249.9x156.2	34.4 to 43.2	36.6 to 45.4	36.6	55.8	156.2
117"*	252.0x157.5	35.1 to 43.2	37.3 to 45.4	36.9	56.1	157.5
118"*	254.2x158.9	35.7 to 43.2	37.9 to 45.4	37.2	56.4	158.8
119"*	256.3x160.2	36.3 to 43.2	38.5 to 45.4	37.5	56.7	160.2
120"*	258.5x161.5	37.0 to 43.2	39.2 to 45.4	37.7	56.9	161.6
121"*	260.6x162.9	37.6 to 43.2	39.8 to 45.4	38.0	57.2	162.9
122"*	262.8x164.2	38.2 to 43.2	40.4 to 45.4	38.3	57.5	164.2
123"*	264.9x165.6	38.8 to 43.2	41.0 to 45.4	38.6	57.8	165.6
124"*	267.1x166.9	39.5 to 43.2	41.7 to 45.4	38.9	58.1	166.9
125"*	269.2x168.3	40.1 to 43.2	42.3 to 45.4	39.1	58.3	168.3
126"*	271.4x169.6	40.7 to 43.2	42.9 to 45.4	39.4	58.6	169.6
127"*	273.5x171.0	41.3 to 43.2	43.5 to 45.4	39.7	58.9	171.0
128"*	275.7x172.3	42.0 to 43.2	44.2 to 45.4	40.0	59.2	172.3
129"*	277.9x173.7	42.6 to 43.2	44.8 to 45.4	40.3	59.5	173.6
130"*	280.0x175.0	43.2	45.4	40.5	59.7	175.1

* For images larger than 100 inches, the interactive function does not work correctly (EB-710Ui only). Images larger than 130 inches are not projected correctly.

• The values are only rough estimates. The value may differ depending on the location where you place the projector.

.

16:9 projected image (EB-700U only)

[Unit: cm]

	S	а	b	С	d	h
Proje	cted image size	Projection Distance Minimum (Wide) to Maximum (Tele)	Numbers on the arm slide scale	Distance to the bottom wall plate installa- tion screw hole	Distance from the top of the projected im- age to the wall plate tempora- ry securing screw hole	Height of pro- jected image
85"	188.2x105.8	16.5 to 35.7	18.7 to 37.9	34.5	53.7	105.8
86"	190.4x107.1	17.1 to 36.5	19.3 to 38.7	34.8	54.0	107.1
87"	192.6x108.3	17.7 to 37.4	19.9 to 39.6	35.2	54.4	108.3
88"	194.8x109.6	18.4 to 38.3	20.6 to 40.5	35.5	54.7	109.6
89"	197.0x110.8	19.0 to 39.1	21.2 to 41.3	35.9	55.1	110.8
90"	199.2x112.1	19.7 to 40.0	21.9 to 42.2	36.3	55.5	112.0
91"	201.5x113.3	20.3 to 40.9	22.5 to 43.1	36.6	55.8	113.3
92"	203.7x114.6	21.0 to 41.8	23.2 to 44.0	37.0	56.2	114.5
93"	205.9x115.8	21.6 to 42.6	23.8 to 44.8	37.3	56.5	115.8
94"	208.1x117.1	22.3 to 43.2	24.5 to 45.4	37.7	56.9	117.0
95"	210.3x118.3	22.9 to 43.2	25.1 to 45.4	38.0	57.2	118.3
96"	212.5x119.5	23.6 to 43.2	25.8 to 45.4	38.4	57.6	119.5
97"	214.7x120.8	24.2 to 43.2	26.4 to 45.4	38.8	58.0	120.8
98"	217.0x122.0	24.8 to 43.2	27.0 to 45.4	39.1	58.3	122.1
99"	219.2x123.3	25.5 to 43.2	27.7 to 45.4	39.5	58.7	123.3
100"	221.4x124.5	26.1 to 43.2	28.3 to 45.4	39.8	59.0	124.6
101"	223.6x125.8	26.8 to 43.2	29.0 to 45.4	40.2	59.4	125.8
102"	225.8x127.0	27.4 to 43.2	29.6 to 45.4	40.5	59.7	127.1
103"	228.0x128.3	28.1 to 43.2	30.3 to 45.4	40.9	60.1	128.3
104"	230.2x129.5	28.7 to 43.2	30.9 to 45.4	41.3	60.5	129.5
105"	232.4x130.8	29.4 to 43.2	31.6 to 45.4	41.6	60.8	130.8
106"	234.7x132.0	30.0 to 43.2	32.2 to 45.4	42.0	61.2	132.0
107"	236.9x133.2	30.7 to 43.2	32.9 to 45.4	42.3	61.5	133.3
108"	239.1x134.5	31.3 to 43.2	33.5 to 45.4	42.7	61.9	134.5
109"	241.3x135.7	31.9 to 43.2	34.1 to 45.4	43.1	62.3	135.7
110"	243.5x137.0	32.6 to 43.2	34.8 to 45.4	43.4	62.6	137.0
111"	245.7x138.2	33.2 to 43.2	35.4 to 45.4	43.8	63.0	138.2
112"	247.9x139.5	33.9 to 43.2	36.1 to 45.4	44.1	63.3	139.5
113"	250.2x140.7	34.5 to 43.2	36.7 to 45.4	44.5	63.7	140.7
114"	252.4x142.0	35.2 to 43.2	37.4 to 45.4	44.8	64.0	142.0
115"	254.6x143.2	35.8 to 43.2	38.0 to 45.4	45.2	64.4	143.2

-Linner Linner

	S	а	b	с	d	h
Proje	ected image size	Projection Distance Minimum (Wide) to Maximum (Tele)	Numbers on the arm slide scale	Distance to the bottom wall plate installa- tion screw hole	Distance from the top of the projected im- age to the wall plate tempora- ry securing screw hole	Height of pro- jected image
116"	256.8x144.5	36.5 to 43.2	38.7 to 45.4	45.6	64.8	144.4
117"	259.0x145.7	37.1 to 43.2	39.3 to 45.4	45.9	65.1	145.7
118"	261.2x146.9	37.8 to 43.2	40.0 to 45.4	46.3	65.5	146.9
119"	263.4x148.2	38.4 to 43.2	40.6 to 45.4	46.6	65.8	148.2
120"	265.7x149.4	39.0 to 43.2	41.2 to 45.4	47.0	66.2	149.4
121"	267.9x150.7	39.7 to 43.2	41.9 to 45.4	47.3	66.5	150.7
122"	270.1x151.9	40.3 to 43.2	42.5 to 45.4	47.7	66.9	151.9
123"	272.3x153.2	41.0 to 43.2	43.2 to 45.4	48.1	67.3	153.1
124"	274.5x154.4	41.6 to 43.2	43.8 to 45.4	48.4	67.6	154.4
125"	276.7x155.7	42.3 to 43.2	44.5 to 45.4	48.8	68.0	155.7
126"	278.9x156.9	42.9 to 43.2	45.1 to 45.4	49.1	68.3	156.9

Images larger than 126 inches are not projected correctly.

• The values are only rough estimates. The value may differ depending on the location where you place the projector.

4:3 projected image (EB-700U only)

[Unit: cm]

	S	а	b	с	d	h
Proje	cted image size	Projection Distance Minimum (Wide) to Maximum (Tele)	Numbers on the arm slide scale	Distance to the bottom wall plate installa- tion screw hole	Distance from the top of the projected im- age to the wall plate tempora- ry securing screw hole	Height of pro- jected image
85"	172.7x129.5	22.0 to 43.2	24.2 to 45.4	31.1	50.3	129.5
86"	174.8x131.1	22.7 to 43.2	24.9 to 45.4	31.4	50.6	131.1
87"	176.8x132.6	23.4 to 43.2	25.6 to 45.4	31.7	50.9	132.6
88"	178.8x134.1	24.2 to 43.2	26.4 to 45.4	32.0	51.2	134.1
89"	180.8x135.6	24.9 to 43.2	27.1 to 45.4	32.3	51.5	135.7
90"	182.9x137.2	25.6 to 43.2	27.8 to 45.4	32.7	51.9	137.1
91"	184.9x138.7	26.3 to 43.2	28.5 to 45.4	33.0	52.2	138.7
92"	186.9x140.2	27.0 to 43.2	29.2 to 45.4	33.3	52.5	140.2
93"	189.0x141.7	27.7 to 43.2	29.9 to 45.4	33.6	52.8	141.7
94"	191.0x143.3	28.4 to 43.2	30.6 to 45.4	33.9	53.1	143.3
95"	193.0x144.8	29.1 to 43.2	31.3 to 45.4	34.3	53.5	144.7
96"	195.1x146.3	29.8 to 43.2	32.0 to 45.4	34.6	53.8	146.3
97"	197.1x147.8	30.6 to 43.2	32.8 to 45.4	34.9	54.1	147.8
98"	199.1x149.4	31.3 to 43.2	33.5 to 45.4	35.2	54.4	149.4
99"	201.2x150.9	32.0 to 43.2	34.2 to 45.4	35.5	54.7	150.9
100"	203.2x152.4	32.7 to 43.2	34.9 to 45.4	35.8	55.0	152.4
101"	205.2x153.9	33.4 to 43.2	35.6 to 45.4	36.2	55.4	153.9
102"	207.3x155.4	34.1 to 43.2	36.3 to 45.4	36.5	55.7	155.4
103"	209.3x157.0	34.8 to 43.2	37.0 to 45.4	36.8	56.0	157.0
104"	211.3x158.5	35.5 to 43.2	37.7 to 45.4	37.1	56.3	158.5
105"	213.4x160.0	36.2 to 43.2	38.4 to 45.4	37.4	56.6	160.0
106"	215.4x161.5	37.0 to 43.2	39.2 to 45.4	37.7	56.9	161.6
107"	217.4x163.1	37.7 to 43.2	39.9 to 45.4	38.1	57.3	163.0
108"	219.5x164.6	38.4 to 43.2	40.6 to 45.4	38.4	57.6	164.6
109"	221.5x166.1	39.1 to 43.2	41.3 to 45.4	38.7	57.9	166.1
110"	223.5x167.6	39.8 to 43.2	42.0 to 45.4	39.0	58.2	167.7
111"	225.6x169.2	40.5 to 43.2	42.7 to 45.4	39.3	58.5	169.2
112"	227.6x170.7	41.2 to 43.2	43.4 to 45.4	39.7	58.9	170.6
113"	229.6x172.2	41.9 to 43.2	44.1 to 45.4	40.0	59.2	172.2
114"	231.6x173.7	42.6 to 43.2	44.8 to 45.4	40.3	59.5	173.7

Images larger than 114 inches are not projected correctly.

¥		
---	--	--


- The values are only rough estimates. The value may differ depending on the location where you place the projector.
- When projecting in Tele, the quality of the projected images may decrease.

Installing the Setting Plate

Connecting Devices

Necessary cables

Be sure to prepare the power cord supplied.




Additionally, prepare the necessary cables according to the devices being used.

- USB connection cable supplied (EB-710Ui only)
- Computer cable supplied (EB-700U only)
- Touch Unit connection cable supplied (EB-710Ui only)
- Other cables (prepare according to the connected devices)

For details, see the projector's User's Guide (on the Document CD-ROM).


Necessary cables when using the Easy Interactive Function (EB-710Ui only)

When performing mouse operations using the Easy Interactive Function, you need a USB cable. Even when projecting using a computer cable, a USB cable is necessary to perform mouse operations.



Necessary cables when installing two projectors in parallel and using the Easy Interactive Function (EB-710Ui only)

When using the interactive function with two projectors installed in parallel, you need the optional remote control cable set (ELPKC28).




When connecting one computer to two projectors and using the interactive function, connect a USB cable from the computer to each projector. You need a computer with two USB-A ports.

Necessary cables when installing the Touch Unit (EB-710Ui only)

You need the supplied Touch Unit connection cable when installing the Touch Unit and connecting it to the projector. Operations are not performed correctly with a commercially available cable.

The shape of the plug that connects to the projector and the plug that connects to the Touch Unit differ. See the following figure to connect to the correct ports.




Installation Procedure


Make sure to follow the steps below to install the setting plate. If these steps are not followed, the product could fall and cause personal injury or property damage.


<u> W</u>arning


Do not use adhesives, lubricants, or oils to install or adjust the setting plate. If you use adhesives to prevent the screws from loosening or things such as lubricants or oils on the slide plate fixing part of the projector, the case may crack and cause the projector to fall, resulting in personal injury or property damage.

Assemble the parts












If the standard position (\boxed{A}) is not correct, loosen the M4 bolt and adjust the position of the slide plate. When you have finished making adjustments, tighten the bolt.



Secure the 3-axis adjustment unit and the slide plate to the base of the projector with the M4 x 12 mm bolts (x4) supplied





Bolt installation positions

Install the wall plate on the wall


Determine the projection position based on the projected image size

See the projection distance table to check the following values.

- Projected image size (S)
- Distance from the top of the projected image to the bottom wall plate installation screw hole (c)
- Distance from the top of the projected image to the wall plate temporary securing screw hole (d)


Projection Distance Table" p.22

Use the screw hole in the following figure as the temporary screw hole for the wall plate. The distance from the bottom wall plate installation screw hole to the temporary screw hole is 192.3 mm.



We recommend marking the following positions. These will be the basis for determining the mounting position of the wall plate.


- Position of the temporary screw hole ($\langle 1 \rangle$)
- Position of the bottom wall plate installation screw hole ($\langle 2 \rangle$)
- Center line ($\langle 3 \rangle$) of the projected image



Attach the template sheet to the wall

- Match the center line (3) checked in step 1 to the Image Center B line on the template sheet.
 Confirm where the beams are within the wall, and shift the position left or right as necessary.
 (The position can be shifted horizontally left or right from the center line of the projection surface up to a maximum of 45 mm.)
- Match the height ($\langle 1 \rangle$) and ($\langle 2 \rangle$) checked in step 1 to the \star lines on the template sheet.


[Unit: mm]



3 Drive a commercially available M10 screw into the position of the temporary screw hole for the wall plate

Leave a gap of 6 mm or more between the wall and the screw head.

- Determine the positions for the mounting holes for the wall plate
 - From the screw holes shown in the figure below, secure at least four points for optimum balance.




6


9

Drill the holes in the wall

Drill diameter: 10.5 mm Pilot hole depth: 45 mm Anchor hole depth: 40 mm




Remove the template sheet, and clean the concrete dust from the holes with a dust pump




Position the wall plate on the wall and insert M10 x 60 mm commercially available anchors into the holes

Attach the nut and tap it with a hammer until the core touches the top of the anchor.



Tighten the nut with a commercially available spanner to secure the wall plate to the wall




Determine the projection distance, and then pass the cables through the setting plate

Check the following values in the projection distance table

- Numbers on the arm slide scale (b)
- Distance from surface of screen to wall (x)
- "Projection Distance Table" p.22


2 Loosen the M4 x 12 mm bolts (x2) and extend the arm slide on the setting plate

Align the slider with the combined distances of (b) and (x) that you checked in step 1.



Route the necessary cables through the setting plate

See the following figure to route the cables so that the ends of the cables that connect to the projector are on the projector's interface side.



Marning

Do not hang the rest of the cable over the setting plate. They could fall and cause an accident.

Route the Touch Unit connection cable through the setting plate (EB-710Ui only). Route the cable so that the end that connects to the Touch Unit appears from the lower part of the setting plate.

Attaching the setting plate to the wall plate

Insert the hexagonal axis into the setting plate


Mount the setting plate to the wall plate

Insert the top of the hexagonal axis into the wall plate, and then insert it into the slot at the bottom.

<u> (</u>Caution


2

- Do not route the Touch Unit connection cable into the wall (EB-710Ui only). If it is wired into the wall, it cannot be connected to the Touch Unit.
- Take care not to trap the cables between the setting plate and wall plate.




3 Secure the setting plate and the wall plate

Secure the supplied M6 screws (x3) with a commercially available No.3 cross-head screwdriver, and then lightly tighten the supplied M6 bolt (x1) with the spanner.




Adjust the vertical slide with the open-ended spanner, and align it with the standard position (\bigcirc)

- Tightening the hexagonal axis at the top (A) raises the setting plate, and loosening the axis lowers it.
- Tightening the M8 bolt at the bottom (B) lowers the setting plate, and loosening the bolt raises it. (You can also use a 17 mm socket wrench.)




1

Tighten the M6 bolt (x1) to fix the setting plate in position




Securing the projector to the setting plate

Loosen the screws (x2) and remove the cable cover from the projector



Attach the 3-axis adjustment unit to the setting plate with the M4 x 12 mm bolts (x4) supplied

- When a projected image is smaller than 85 inches: Mount the unit at the \bigcirc stamp (\boxed{A}).
- When a projected image is 85 inches or more: Mount the unit at the $\bigcirc \bigcirc$ stamp (\square).




Connect the cables to the projector


"Connecting Devices" p.37

Connect the power cord last.

Use commercially available M4 screws to secure peripheral devices and accessories such as external tuners to the screw holes in the following figure.



Install the optional wireless LAN module in the wireless LAN unit module slot.



Adjusting the Position of the Projector

- Images are not stable immediately after turning on the projector. Wait for at least 10 minutes before adjusting the image after starting projection.
- Do not make adjustments using the projector's Keystone function. Doing so may result in a reduction in image quality.
- When setting up multiple projectors using the batch setup function, perform the batch setup before adjusting the projected image.
 - "Batch Setup Function" p.110

.....


When installing the Touch Unit (EB-710Ui only), if there are any obstacles at the bottom of the whiteboard such as a frame or trays, stick the infrared deflectors along the bottom edge of the whiteboard before adjusting the projector.


"Sticking the infrared deflectors (EB-710Ui only)" p.55

Press the [Power] button on the remote control or the control panel to turn on the projector

Using the Remote Control

Using the Control Panel






<u> C</u>aution

While projecting, do not put your face or hands near the air exhaust vent, and do not place objects that may become warped or damaged by heat near the vent. Hot air from the air exhaust vent could cause burns, warping, or accidents to occur.

2 Open the air filter cover, and then adjust the focus using the focus lever




Fine-tune the focus later.

After you finish making adjustments, close the air filter cover.


• You can change the display language from Language on the Extended menu.

Projector's User's Guide - Projector menu

• When you turn on the projector for the first time, the message **"Do you want to set the time?"** is displayed. If you set it later, select **No**.




- 6 After loosening the adjustment dial at the bottom, adjust the horizontal roll using the adjustment dial at the top.
 - Repeat steps 6 to 11 as necessary.




After you finish making adjustments, tighten the adjustment dial at the bottom.

Loosen the M4 screw (x1) with the hexagon wrench, and then adjust the horizontal rotation with the adjustment dial




After you finish making adjustments, tighten the M4 screws that you loosened.

8 After loosening the adjustment dial at the bottom, adjust the vertical tilt using the adjustment dial at the top.





After you finish making adjustments, tighten the adjustment dial at the bottom.

Loosen the M4 bolt with the hexagon wrench, and then adjust the horizontal slide



After you finish making adjustments, tighten the M4 bolt that you loosened.







After you finish making adjustments, tighten the M4 bolts that you loosened.

Loosen the M6 bolt (x1) with the open-ended spanner, and then adjust the vertical slide Adjust the vertical slide with the hexagonal axis at the top or the bottom.

- Tightening the hexagonal axis at the top raises the setting plate, and loosening the axis lowers it.
- Tightening the M8 bolt at the bottom lowers the setting plate, and loosening the bolt raises it. (You can also use a 17 mm socket wrench.)



After you finish making adjustments, tighten the M6 bolt that you loosened.




<u> (</u>Warning

Tighten all bolts and screws firmly. Otherwise, the product may fall and cause personal injury or property damage.

Adjust the focus to match the focus in the following figure ([A])

Open the air filter cover, and then adjust the focus.

When (A) is in focus, check the (B) areas. If any of the (B) areas are out of focus, adjust the focus until the (B) areas are uniform.




After you finish making adjustments, close the air filter cover.

Press the [Esc] button on the remote control or the control panel to remove the guidance screen

Sticking the infrared deflectors (EB-710Ui only)

When installing the Touch Unit, if there are any obstacles at the bottom of the whiteboard such as a frame or trays, touch operations will not operate correctly. If there are any obstacles, stick the infrared deflectors along the bottom edge of the whiteboard before adjusting the position of the projector.

-WWW




- Do not remove an infrared deflector once it has been stuck in place. This can weaken the adhesive strength of the tape.
 - Do not stick tape or place anything on the infrared deflectors. The infrared deflector will not function correctly.


Arc Correction

When fine-tuning the shape of the projected image, perform Arc Correction.


Turn on the projector, and then press the [Menu] button

Using the Remote Control





2 Select Geometry Correction from Settings





4

[Geometry Correction] Return H/V-Keystone Quick Corner Arc Correction

Select Arc Correction



5	Select the side you want to correct
	[Arc Correction]
	Select the area.

Correct the selected side

If the message **"Cannot adjust any further."** is displayed while adjusting, you cannot adjust the shape any further in the direction indicated by the gray triangle.

[Arc Correction]		
Â		
Perform the adjustment.		



6

Repeat steps 5 and 6 as needed to adjust any remaining sides

Calibrating the Pen (EB-710Ui only)

Check that adjusting the position of the projector is complete before you start calibrating the interactive pen.

"Adjusting the Position of the Projector" p.49

There are two methods available for calibrating the pen; **Auto Calibration** and **Manual Calibration**. When calibrating the pen for the first time after installing the projector, perform **Manual Calibration** for optimum calibration.

For the Auto Calibration method, see the projector's User's Guide (on the Document CD-ROM).


When two projectors are installed in parallel and you are using the interactive function, set the multiprojection interactive features before adjusting the pen.

☞ "When two projectors are installed in parallel and you are using the interactive function (EB-710Ui only)" p.101

3

Turn on the projector, and then press the [Menu] button

Using the Remote Control




Select Easy Interactive Function from Extended

Image		Return
Signal	 Easy Interactive F Home Screen 	unction
Settings	Display User's Logo Projection	Front
Extended G		From
Network	USB Type B Multi-Projection	USB Display
ECO	Language S Reset	English
Info	Reset	
Reset		


Select Manual Calibration


Image	[Easy Interactive Func	tion] Return
Signal	[General]	
Settings	 Auto Calibration Manual Calibration Touch Unit Setup 	0
Extended		PC Free Annot
Network	Advanced	
ECO	[PC Interactive]	Windows /Mon
Info	 Pen Operation Mode Enable Right Click Advanced 	Windows/Mac Off
Reset	Advanced	




Touch the center of the dot with the pen tip of the interactive pen

The dot disappears and moves to the next position.









Repeat step 5 until all of the dots disappear

The dot appears at the top left first and then moves towards the bottom right.





When all of the dots disappear, calibration is complete.




Attaching the Covers


Attach the wall plate covers Install the right cover first.







Attach the cable cover to the projector, and then secure it with the screws (x2)



🕂 Caution

Only a specialist should remove or reinstall the projector, including for maintenance and repairs. See the projector's *User's Guide* for instructions on maintenance and repairs.

🕂 Warning

- Never loosen the bolts and nuts after installation. Confirm that the screws have not become loose on a regular basis. If you find any loose screws, tighten them firmly. Otherwise, the product may fall and cause personal injury or property damage.
- Do not hang on this product or hang a heavy object on this product. If this product falls, it could cause death or personal injury.

Installing the Touch Unit (EB-710Ui only)

Check that the following procedures have been completed before installing the Touch Unit.

- Installing the Projector (
 p.37)

The procedure differs depending on where the Touch Unit is to be installed.

- When installing the Touch Unit outside the whiteboard (using the Touch Unit Bracket) (
 p.65)
- When installing the Touch Unit on the whiteboard (without using the Touch Unit Bracket) (
 p.89)

When installing the Touch Unit outside the whiteboard (using the Touch Unit Bracket)

Installation Procedure


Install the Touch Unit outside the whiteboard using the Touch Unit Bracket and connect it to the projector. Check that the screen is parallel to the surface on which the Touch Unit is installed.


\Lambda Caution

Only connect the projector to the EB-710Ui. Do not connect it to any other Touch Units or devices.

Turn on the projector, and then press the [Menu] button

Using the Remote Control






2

Select Easy Interactive Function from Extended

Image		Return
Signal	Easy Interactive F Home Screen	unction()
Settings	Display User's Logo Projection	Front
Extended	Operation A/V Settings	- Tont
Network	USB Type B Multi-Projection	USB Display
ECO	Language 📀 Reset	English
Info		
Reset		




Select Touch Unit Setup




Select Installation Pattern


Image	[General]	Return
Signal	[Touch Unit Setup]	
Settings	Installation Pattern Power Angle Adjustment	Off
Extended G		
Network		
ECO		
Info		
Reset		


The installation pattern is displayed on the projected image.



Loosen the screw at the bottom of the dial cover using a commercially available No.2 crosshead screwdriver








7 Determine the installation position for the Touch Unit Bracket

We recommend marking the following installation positions (positions of the screw holes) to make installation easier.


 $(\langle 1 \rangle)$: Center line of installation pattern. Align with the center line ($\langle 3 \rangle$) of the installation plate.

((2)): 25 to 100 mm from the top edge (white line) of the projected image. Align with the bottom line of the installation plate.




9

Install the installation plate using three M4 commercially available 4 mm wood screws, or three M4 anchor bolts.




Attach the securing plate to the rear of the Touch Unit with the two M4 x 25 mm bolts supplied


Adjust the position so that the two screw holes of the Touch Unit and the two screw holes of the securing plate are aligned. Tighten the bolts to the securing plate using the supplied hexagon wrench.






There is a powerful magnet on the rear of the Touch Unit. Do not trap your hand between the Touch Unit and the securing plate.






Measure the distance from the wall to the surface of the screen (f)



13

Adjust the height of the left and right according to the value (f) measured in step 11

Loosen the two screws and move the Touch Unit back and forth to adjust the left and right so that the arrow aligns with the value on the scale the same as (f). When you have finished adjusting, tighten the two screws.




Secure the Touch Unit and the installation plate with the hexagon socket head cap bolt


The bolt used varies according to the distance (f) from the wall to the surface of the screen measured in step 11. Tighten the bolt to the installation plate using the supplied hexagon wrench.

When (f) = 20 to 35 mm: M4 x 55 mm bolt

When (f) = 35 to 50 mm: M4 x 70 mm bolt




Connect the Touch Unit connection cable that is connected to the projector to the TCH port on the Touch Unit




Angle Adjustment

An infrared laser in the shape of a curtain is emitted from the Touch Unit. The infrared laser reflects off your finger when touched to the whiteboard thereby detecting the finger position allowing the projector's infrared camera to recognize the position being reflected.




Adjust the angle of the laser light coming from the Touch Unit so that the projector can correctly detect the position of your finger.




C: Vertical movable point

If the laser is not emitted parallel to the screen, the projector will not detect touch operations or the position of your finger correctly.



If there are any obstacles at the bottom of the whiteboard such as a frame or trays, the laser will be reflected and the location of your finger will not be detected correctly. Stick infrared deflectors on the frame and the trays to prevent them from reflecting the laser.

"Sticking the infrared deflectors (EB-710Ui only)" p.55



• When two projectors are installed in parallel and you want to use the interactive function, set the multiprojection interactive features in advance.

TWhen two projectors are installed in parallel and you are using the interactive function (EB-710Ui only)" p.101


• Before adjusting the angle, make sure that interactive pen calibration is complete.

"Calibrating the Pen (EB-710Ui only)" p.58

WWW

2


Select Easy Interactive Function from the projector's Extended menu




Select Touch Unit Setup

Image	[Easy Interactive Func	tion] Return
Signal	[General]	
Settings	Auto Calibration Manual Calibration Touch Unit Setup	
Extended 🥥	Pen Mode	PC Free Annot
Network	Hovering Advanced	Off
ECO	[PC Interactive]	
Info	 Pen Operation Mode Enable Right Click Advanced 	Windows/Mac Off
Reset		

Set **Power** to **On**



The Touch Unit power turns on and the indicator is lit blue.






4


When **Power** is set to **On**, the next time the projector is turned on, the Touch Unit automatically turns on.

Select Angle Adjustment







Select Installing the Touch Unit with the bracket





The following screen is displayed.



Turn the adjustment screw for the Touch Unit fully clockwise using the hexagon wrench supplied with the setting plate







When you hear a clicking sound coming from the adjustment dial, stop turning, and then press the [] button on the remote control. The following screen is displayed.


	[Angle Adjustment] Preparation	
	Step: 1. Attach the Markers to the Marker Positions, and Pointers should appear. If the Pointers do not appear, turn Adjustment Dials. 2. Turn the Adjustment Dials until Pointers move inside the Targets. The Angle Adjustment is completed when both the Pointers have turned solid.	
	Attention: - Do not place hands or other obstacles on the screen during adjustment. - Do not place any objects between the projector and markers during adjustment.	
\bigcirc	Marker Position O O Pointer Adjustment Dial Target	\bigcirc
Ŭ		Ŭ
	[Esc]:Back [@]:Next [Menu]:Exit	
*		X

8 Attach the supplied two markers to the marker positions (\checkmark) (\searrow) on the projection


screen

-


Match the positions so that the crosses (\mathbb{B}) for the markers overlap with the points ($\overline{\mathbb{A}}$) for the (\checkmark) (\checkmark).



- Magnetic screens: Place the bottom of the markers onto the screen.
- Non-magnetic screens: Use the supplied tape to secure the markers. Attach the tape so that the either end of marker does not come loose off the screen.



Do not place anything other than the markers near the projected image during angle adjustment. If other objects are on the projected image, angle adjustment may not be performed correctly.



When the pointers overlap in the correct position, the colors become solid () ().

Turn the adjustment screw clockwise to move the pointer down as needed.

o. All	Image: Adjustment image: Properties of the Pointers move inside the Targets. The Adjustment Dials until Pointers move inside the Pointers of the Adjustment Dials until Pointers move inside the Pointers of the Pointers. Image: Pointer Pointer Pointer Image: P	0~

- When turning the adjustment screw, make sure shadows from your arm or body do not overlap with the markers.
 - If the pointers are not solid colors (
) (
), check if the Touch Unit and screen are parallel.
 Adjust the Touch Unit Bracket so that the Touch Unit and screen are parallel.

When the pointers on the left and right become solid colors () (), press the [4] button on the remote control


The following screen is displayed.

10


	[Angle Adjustment] Preparation	
	Step: 1. Attach the Markers to the Marker Positions, and Pointers should appear. If the Pointers do not appear, turn Adjustment Dials. 7. Turn the Adjustment Dials until Pointers move inside the Targets. The Angle Adjustment is completed when both the Pointers have turned solid.	
	Attention: Do not place hands or other obstacles on the screen during duistment. Do not place any objects between the projector and markers during adjustment.	
\bigcirc	Marker Position O O Pointer Adjustment Dial O Target	
	[Esc]:Back [Q]:Next [Menu]:Exit	
<u>H</u>	No. (No. 1997)	

Turn the adjustment dials on the Touch Unit to move the pointers (\bigcirc) (\bigcirc) so that they overlap with the target (\bigcirc) (\bigcirc) of the same color on either side

When you turn the adjustment dial clockwise, the pointer moves diagonally up towards the center of the projected image.



When you turn the adjustment dial counterclockwise, the pointer moves diagonally down away from the center of the projected image.



When the pointers overlap in the correct position, the colors become solid (


If you hear a clicking sound from the dial, the pointer does not move any further.
When turning the dials, make sure shadows from your arm or body do not overlap with the markers.

) (

).


12 When the pointers on the left and right become solid colors () (), press the [-] button on the remote control

The following screen is displayed.



Place the markers at the top marker positions [1] (\checkmark) (\checkmark)


When angle adjustment is performed correctly, the upper pointers become solid colors () ().



If the upper pointers do not become solid colors () (), start again from step 1.

Place the markers at the bottom marker positions [2] (\checkmark) (\searrow)

When angle adjustment is performed correctly, the bottom pointers become solid colors (🔵) (🛑).



If the bottom pointers do not become solid colors () (), start again from step 4.

When you have finished checking, remove the markers, and then press the [+] button on the remote control

The following screen is displayed.

•
[Angle Adjustment] Preparation
Step: 1. Remove the Markers. 2. Erase the dots around the image by tracing them with your finger. 3. When all of the dots have disappeared, select "Complete".
If dots remain on the sides: Remove any obstacles near the dots. If there are obstacles that you cannot remove, select "Additional Adjustment".
If dots remain on the bottom: Place the included infrared deflectors under the dots.
Attention: - Dats will be displayed again when you press the a or a button. - You cannot draw or have computer interactivity in the area where the dots remain.
Complete 🕘 Additional Adjustment
[Esc]:Back [4]:Select [0]:Enter [Menu]:Exit
 •••••••••••••••••••••••••••••••••••••••

W

<text><text>

Touch operations may not perform correctly if you are wearing artificial nails or nail polish, or if your fingers are obstructed by bandages and so on.

When all of the dots have disappeared, select **Complete** and press the [+] button on the remote control. Then, go to step 17.


If some dots remain as shown in the following figure, check the following points.

[Angle Adjustment] Preparation Step: 1. Remove the Markers. 2. Erase the dots around the image by tracing them with your finger. 3. When all of the dots have disappeared, select "Complete". If dots remain on the sides: Remove any obstacles near the dots. If there are obstacles that you cannot remove, select "Additional Adjustment". If dots remain on the bottom: Place the included infrared deflectors under the dots. Attention:	
Attention: • Dots will be displayed again when you press the or putton. • You cannot draw or have computer interactivity in the area where the dots remain. • Complete • Additional Adjustment • Complete • Adjustment • Compl	


If the dots on the left and right do not disappear: Remove any obstacles that are on the left and right of the projection screen. After removing any obstacles, press the [) or [] button on the remote control, and then perform step 16 again. Perform additional adjustment if dots still remain even after performing this step, or if there are obstacles that cannot be removed such as whiteboard trays or frames.

Additional adjustments" p.84






When you have finished making adjustments, perform a touch calibration.




Additional adjustments

Perform additional adjustments if the dots on the left and right remain after adjusting the angle.


If the laser crosses the frame of the screen, it reflects within the screen and touch operations cannot be performed correctly. Additional adjustments adjust the height of the laser beam so that it does not cross the frame on the left and right.



1 Select Additional Adjustment



The following screen is displayed.



After this, adjust using the same procedure for angle adjustment from step 11. Follow the on-screen instructions to make adjustments.

Angle Adjustment" p.71

When you have finished making adjustments, perform a touch calibration.

WWW

Make sure you store the markers in a safe place.

Touch Calibration

Perform touch calibration so that the projector can recognize touch operations precisely.


When two projectors are installed in parallel and you are using the interactive function, check the following before performing touch calibration.
 The multi-projection interactive features are set


Twhen two projectors are installed in parallel and you are using the interactive function (EB-710Ui only)" p.101

Both projectors and the Touch Unit are turned on

Press the projector's [Menu] button

Using the Remote Control






2

3

Select Easy Interactive Function from Extended




Select **Touch Unit Setup**


Image	[Easy Interactive Funct	tion] Return
Signal	[General]	
Settings	 Auto Calibration Manual Calibration Touch Unit Setup 	
Extended		PC Free Annot
Network	Advanced	
ECO	[PC Interactive]	
Info	 Pen Operation Mode Enable Right Click Advanced 	Windows/Mac Off
Reset		



Select Touch Calibration



The focus adjustment message is displayed.



Attention: Do not place hands or other obstacles on the screen during adjustment.


- Touch each mark shown on the screen with your finger. Keep touching the marks until they move.
- Continue until you have touched all of the marks up to the final mark at the bottom-right.

No


Calibration starts when preparations are complete. Do you want to continue?

Yes 🕲

A dot is displayed at the top left of the projection screen.



Repeat step 6 until all of the dots disappear



When all of the dots disappear, touch calibration is complete.

 If you touch the wrong position, press the [Esc] button on the remote control or control panel. This returns you to the previous dot. You cannot go back by two dots.

- To cancel touch calibration, hold down the [Esc] button for two seconds.
- It may take several seconds after all of the dots have disappeared until touch calibration is complete.

When installing the Touch Unit on the whiteboard (without using the Touch Unit Bracket)

About installation

- There are magnets built into the back of the Touch Unit. Normally, the Touch Unit should be installed by attaching the magnets to the screen.
- If the magnets cannot be attached to a screen, use commercially available M4 screws (x3).
- Attach the Touch Unit to the same level surface as the screen surface.

Installation Procedure


Install the Touch Unit, and then connect to the projector.

🕂 Caution


Only connect the Touch Unit to the EB-710Ui. Do not connect it to any other projectors or devices.

Turn on the projector, and then press the [Menu] button

Using the Remote Control









2

Select Easy Interactive Function from Extended






Select Touch Unit Setup




Select Installation Pattern

Image	[General]	Return
Signal	[Touch Unit Setup]	
Settings	Power	Off
Extended	Angle Adjustment Touch Calibration	
Network		
ECO		
Info		
Reset		


The installation pattern is displayed on the projected image.



Loosen the screw at the bottom of the dial cover using a commercially available No.2 crosshead screwdriver



7




Determine the installation position for the Touch Unit

We recommend marking the following installation positions to make installation easier.

 $(\langle 1 \rangle)$: Center line of installation pattern. Align with the center line of the Touch Unit ($\langle 3 \rangle$).

($\langle 2 \rangle$): 25 to 100 mm from the top edge of the projected image. Align with the bottom edge of the Touch Unit.




Secure the Touch Unit


• Magnetic screens: Place the back of the Touch Unit on the screen surface, and then secure.

🕂 Caution


When installing the Touch Unit on a magnetic surface, be careful not to trap your fingers or any other part of your body between the magnets and the installation surface. Powerful magnets are used which can cause injury if you trap your fingers.



• Non-magnetic screens: Attach spacers and secure with M4 screws (x3).




[Unit: mm]



Screw hole cross-section

9 Connect the Touch Unit connection cable that is connected to the projector to the TCH port on the Touch Unit



Angle Adjustment

WWW

This section explains how to adjust the angle of the Touch Unit. For details on angle adjustment, see p.71.


• When two projectors are installed in parallel and you want to use the interactive function, set the multiprojection interactive features in advance.

☞"Multi-Projection settings" p.97

• Before adjusting the angle, make sure that interactive pen calibration is complete.

"Calibrating the Pen (EB-710Ui only)" p.58


Select **Easy Interactive Function** from the projector's **Extended** menu




Select Touch Unit Setup

Image	[Easy Interactive Funct	tion] Return
Signal	[General]	
Settings	Auto Calibration Manual Calibration Touch Unit Setup	0
Extended 🥑	Pen Mode	PC Free Annot
Network	Advanced	Off
ECO	[PC Interactive]	
Info	Pen Operation Mode Enable Right Click Advanced	Windows/Mac Off
Reset	Advanced	

Set **Power** to **On**



The Touch Unit power turns on and the indicator is lit blue.






4


When **Power** is set to **On**, the next time the projector is turned on, the Touch Unit automatically turns on.

Select Angle Adjustment






Select Installing the Touch Unit without the bracket




The following screen is displayed.



The next procedures are the same as for adjusting the angle (after step 11) when installing outside the whiteboard using the bracket.


"Angle Adjustment" p.71



When you have finished making adjustments, perform a touch calibration.

Installing Multiple Projectors in Parallel (Multi-Projection)

By installing multiple projectors in parallel, you can project one, large image (Multi-Projection).



Check the following when installing multiple projectors in parallel. (
"Installation Work Flow" p.11)

When projecting the screen from one computer, you need to make the following preparations. See the documentation provided with your computer to check how to make settings.


- Connect a cable from one computer to each projector (the computer needs two image output ports)
- Set to output images to multiple screens from one computer

Multi-Projection settings


Follow the steps below when using the Multi-Projection function.

Setting the Projector ID

Turn on the projector, and then press the [Menu] button




2



Select Multi-Projection from Extended

3 Select Projector ID




Select the ID number for the target projector


Off 1 2 3 4 5 6 7 8 9	[Projector ID]		Return 🕘	
		01 02 03 04 05 06 07 08		

5


4

Press the [Menu] button to close the menu Repeat steps 1 to 5 for the remaining projectors.






The ID set for the projector is displayed on the projected screen. The display turns off after approximately three seconds.




While holding down the [ID] button, press the button with the same number as the projector ID for the projector you want to operate



Remote control operations for the projector with the selected ID are enabled.

Press the [ID] button and check the ID setting



The following is displayed.

- Remote Control: On is displayed: You can operate the projector currently being operated.
- Remote Control: Off is displayed: You cannot operate the projector with the remote control. Repeat the procedure above to enable remote control operations.
 - Each time the projector is turned on, you need to select the projector ID for the projector you want to operate. When the projector is turned on, the ID set for the remote control is 0.
 - When **Projector ID** is set to **Off**, you can operate the projector using the remote control regardless of the ID setting selected using the remote control.
 - When the remote control ID is set to 0, you can operate all of the projectors regardless of the projector ID setting.

Adjusting the Image in Multi-Projection

- Check that projector position adjustment is complete
 - "Adjusting the Position of the Projector" p.49
- If you are concerned about the alignment between images being projected in multi-projection, try performing Arc Correction.
 - Arc Correction" p.57

Menu


Turn on the projector, and then press the [Menu] button

Ó

Pointer


Using the Remote Control

Using the Control Panel



Select Multi-Projection from Extended





Press the [Esc] button to return to the previous screen.

Δ	Make each setting	
	Color Mode	Set the same item for each projector.
	Color Uniformity	Adjust the color balance for the entire screen (only when necessary).
	Brightness Settings	If the brightness of the light source for each projector is different, adjust the brightness of the light source. Adjust the darkest projector as the standard.
	Color Matching	Adjust the color and brightness in gradations from all white to all black.

When two projectors are installed in parallel and you are using the interactive function (EB-710Ui only)

When two projectors are installed in parallel and you want to use the interactive function, after adjusting the image for multi-projection, make the following settings. Make the settings for each projector in turn. You cannot set the two projectors at the same time.



B

Setting Projector Synchronization (
 p.101)

2 Setting Multi-Projection Interactive (
 p.103)

When two images overlap, the interactive function does not work correctly.

Setting the projectors in sync


When using the interactive function for multi-projection, interactive pen operations become unstable due to infrared interference. Follow the steps below to stabilize operations for the interactive pen. Check that installation is complete for both projectors before making settings.

Installing the Setting Plate


Connect the SYNC ports for each projector by using the optional remote control cable set (ELPKC28)

When the projectors are connected by cable, operations for the interactive pen stabilize.


The SYNC port has an IN and OUT socket. When you connect one end of the remote control cable set to an IN socket, connect the other end to an OUT socket.



Turn on the projector, and then press the [Menu] button









3

2


Select Easy Interactive Function from Extended



Select **Advanced**



Set Sync of Projectors to Wired




Setting Multi-Projection Interactive

Before setting Multi-Projection Interactive, check that you have finished adjusting the image for multi-projection. If you perform image adjustment after setting interactive, the pen position may not be correct.

"Adjusting the Image in Multi-Projection" p.100


The procedure differs depending on whether or not the Touch Unit is used.

When not using the Touch Unit



4


5



Select Easy Interactive Function from Extended

Signal (Easy Interactive Function) Home Screen
Non out
Settings Display User's Logo Projection Front
Extended 🕘 Operation
A/V Settings Network USB Type B USB Display Multi-Projection
ECO Language C English Reset
Info
Reset

Select Advanced from General




Select Multi-Projection

I S

F


			_
Image	[General]	Return	
Signal	[Advanced]		
Settings	Distance of Projectors Sync of Projectors	Infrared	
	Multi-Projection	Dott)	
Extended 🛛 🙂	Wired Sync Mode	Mode 1	
	Preset Pen Thickness	Normal	
Network	Eraser Size	Normal	
	Color Palette	Palette 1	
ECO			
	[PC Free Annotation]		
Info	Pen Button Function	Eraser	
	Default Touch Action	Eraser	
Reset	Confirm Clear Screen	Off	




```
11
```

Calibrate the pen (
 p.58)

When using the Touch Unit (EB-710Ui only)




Select Easy Interactive Function from Extended





Select Advanced from General




Select Multi-Projection

1


I

Image	[General]	Return	
Signal	[Advanced]		
Settings	Distance of Projectors Sync of Projectors	Mode 1 Infrared	5
		DOff	2
Extended 🛛 🕑		Mode 1	R
Network	Preset Pen Thickness Eraser Size	Normal Normal	5
	Color Palette	Palette 1	
ECO			
	[PC Free Annotation]	_	
Info	Pen Button Function	Eraser	2
Reset	Default Touch Action Confirm Clear Screen	Eraser Off	6

6 Select Left







- When installing the Touch Unit on the whiteboard (without using the Touch Unit Bracket)
 - Installing the Touch Unit (
 p.89)
 - Adjusting the Angle of Laser Diffusion (
 p.93)

Turn on the projectors on the left and right



Batch Setup Function

After making the projector's menu settings for one projector, you can copy the settings to other projectors (batch setup function). The batch setup function is only for projectors with the same model number.

Use one of the following methods.

- Setup using a USB flash drive.
- Setup by connecting the computer and projector with a USB cable.
- Setup using EasyMP Network Updater.

This guide explains the USB flash drive and the USB cable methods.

- The following menu settings are not copied by the batch setup function.
- Network menu settings (except for the Notifications menu and the Others menu)
- Perform batch setup before adjusting the position of the projectors. Adjustment values for the projected image, such as Keystone, are copied by the batch setup function. If batch setup is performed after adjusting the position of the projectors, the adjustments you made may change.
- By using the batch setup function, the registered User's Logo is copied to the other projectors. Do not register confidential information and so on as the User's Logo.

🕂 Caution

Performing batch setup is the customers responsibility. If batch setup fails due to a power failure, communication error, and so on, the customer is responsible for any repair costs incurred.

Setup Using a USB flash drive

This section explains how to perform batch setup using a USB flash drive.

- **≨**—] Use a l
 - Use a FAT format USB flash drive.
 - The batch setup function cannot be used by USB flash drives that incorporate security functions. Use a USB flash drive that does not incorporate security functions.
 - The batch setup function cannot be used by USB card readers or USB hard disks.

Saving settings to the USB flash drive

Disconnect the power cord from the projector, and check that all of the projector's indicators have turned off

2

Connect the USB flash drive to the projector's USB-A port

• Connect the USB flash drive directly to the projector. If the USB flash drive is connected to the projector through a USB hub, the settings may not be saved correctly.

- Connect an empty USB flash drive. If the USB flash drive contains data other than the batch setup file, the settings may not be saved correctly.
- The file name for the batch setup file is PJCONFDATA.bin. If you need to change the file name, add text after PJCONFDATA. If you change the PJCONFDATA section of the file name, the projector may not be able to recognize the file correctly.
- You can only use single-byte characters for the file name.

While holding down the [Esc] button on the remote control or the control panel, connect the power cord to the projector

The On/Standby indicator and the Status indicator turn blue, and the Laser indicator and the Temp indicator turn orange.

When all of the projector's indicators turn on, release the [Esc] button.



When all of the indicators start flashing, the batch setup file is being written.

🔨 Caution


- Do not disconnect the power cord from the projector while the file is being written. If the power cord is disconnected, the projector may not start correctly.
- Do not disconnect the USB flash drive from the projector while the file is being written. If the USB flash drive is disconnected, the projector may not start correctly.

When writing completes normally, the projector turns off, and only the On/Standby indicator is lit blue.



When the power turns off, remove the USB flash drive.

Copying saved settings to other projectors



Connect the USB flash drive containing the saved batch setup file to the projector's USB-A port

Do not store any data except for the batch setup file on the USB flash drive. If the USB flash drive contains data other than the batch setup file, the settings may not be reflected copied correctly.

3

2


While holding down the [Menu] button on the remote control or the control panel, connect the power cord to the projector

The On/Standby indicator and the Status indicator turn blue, and the Laser indicator and the Temp indicator turn orange.

When all of the projector's indicators turn on, release the [Menu] button. The indicators turn on for approximately 75 seconds.



When all of the indicators start flashing, the settings are being written.





- Do not disconnect the power cord from the projector while the settings are being written. If the power cord is disconnected, the projector may not start correctly.
- Do not disconnect the USB flash drive from the projector while the settings are being written. If the USB flash drive is disconnected, the projector may not start correctly.

When writing completes normally, the projector turns off, and only the On/Standby indicator is lit blue.




When the power turns off, remove the USB flash drive.





Do not disconnect the power cord from the projector while the settings are being written. If the power cord is disconnected, the projector may not start correctly.

When writing completes normally, the projector turns off, and only the On/Standby indicator is lit blue.




When Setup Fails

Check	Remedy		
Are the Laser indicator and the Temp in- dicator flashing orange quickly?	The batch setup file may be corrupt, or the USB flash drive or USB cable may not be connected correctly. Disconnect the USB flash		
	drive or the USB cable, unplug and then plug in the projector's power cord, and then try again.		
Ċ ★ ▲ On/Standby Status Laser Temp			
Are the On/Standby indicator and the Sta- tus indicator flashing blue quickly, and the Laser indicator and the Temp indicator flashing orange quickly?	Writing the settings may have failed and an error may have occurred in the projector's firmware. Stop using the projector, remove the power plug from the electrical outlet, and contact Epson for help.		
On/Standby Status Laser Temp			

Attaching a Security Cable

A commercially available theft-prevention wire lock can be attached to this product.

Pass the wire for the theft-prevention wire lock through the security cable installation points on the projector and the setting plate. See the user's guide supplied with the wire lock for locking instructions.




The security slot on this product is compatible with the Microsaver Security System manufactured by Kensington. See the following for more details on the Microsaver Security System.


http://www.kensington.com/

Projector

Touch Unit (EB-710Ui only)

(cannot be used when attached to bracket)







Mac and OS X are trademarks of Apple Inc.

Microsoft and Windows are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.

©SEIKO EPSON CORPORATION 2017. All rights reserved.